




INCRA Imperial Scales

INCRA PARTS & COMPONENTS/ INCRA Scales



LIST OF COMPONENTS:

ID#	PART NUMBER	NAME OF COMPONENT
1	PSCA-808C	Lexan Scale, 8"-0-8" (8" at each end, 0" in the center)
2	PSCA-0016R	Lexan Scale, 0"-16" (0" on the left, 16" on the right)
3	PSCA-1632R	Lexan Scale, 16"-32" (16" on the left, 32" on the right)
4	PSCA-3248R	Lexan Scale, 32"-48" (32" on the left, 48" on the right)
5	PSCA-4864R	Lexan Scale, 48"-64" (48" on the left, 64" on the right)
6	PSCA-1600S	Lexan Scale, 16"-0" (16" on the left, 0" on the right)
7	PSCA-3216S	Lexan Scale, 32"-16" (32" on the left, 16" on the right)
8	PSCA-4832S	Lexan Scale, 48"-32" (48" on the left, 32" on the right)
9	PSCA-6448S	Lexan Scale, 64"-48" (64" on the left, 48" on the right)
10	PSCA-8064S	Lexan Scale, 80"-64" (80" on the left, 64" on the right)
11	PSCA-9680S	Lexan Scale, 96"-80" (96" on the left, 80" on the right)
12	PSCA-3200SS	Stainless Steel Scale 32"-0" w/Magnetic Tape
13	PSCA-2500SS	Stainless Steel Scale 25"-0" w/Magnetic Tape
14	PSCA-1600SS	Stainless Steel Scale 16"-0" w/Magnetic Tape

PLEASE REFER TO THE WEBSITE FOR THE LATEST PRICING.

Refer to the part number(s) when ordering. To order, go to www.incrementaltools.com or call 1-888-804-6272.