


INCRA TS-LS Super System

INCRA PARTS & COMPONENTS/ Table Saw Fence Systems



> Continued on next page for list of components.



LIST OF COMPONENTS:

ID#	PART NUMBER	NAME OF COMPONENT
1	LS32	LS32 Base and Carriage Assy Complete
2A	PTSL-600400	TS-LS Standard Base Support Panel, 28.5"
2B	PTSL-600500	TS-LS XL Base Support Panel, 34"
2C	PTSL-600600	TS-LS XL Base Support Panel, 40"
3	PWFN-500400	Dust Collection Elbow
4	RAFJUMBO	Jumbo Right Angle Fixture Assy (Complete)
5	PTSL-700100	Fence Glide Assy (Infeed)
6	PKNB-100200	Knob, 1/4"-20 x 3/4" (Infeed Fence Glide)
7A	PTSL-600100	TS-III A Standard Rip Fence, 36"
7B	PTSL-600200	TS-III A XL Rip Fence, 46.5"
8	PFST-800100	Sub Fence Mounting Hardware Pack
9	PFST-200300	Nut, Rectangular 1/4"-20 (Narrow Body)
10	WF/ULTRA	Wonder Fence Upgrade Assembly (Complete)
11	SHOPSTOP	Shop Stop Assy (Complete)
12	PTSL-700200	Fence Glide Assy (Outfeed)
13	PTSL-800300	Rail Stop Set, Floating Pair
14	PTSL-500100	Base Clamp Glide Pads (Black), Pair
15	PTSL-800500	TS-LS Base Mount & Rails Master Hdwr Pack w/ Hex Tool
16A	PTSL-600700	Rail Extrusion, 72"
16B	PTSL-600800	Rail Extrusion, 92"
17	PTSL-800400	Base Clamping Knob Set
18	PKNB-100700	Knob, 3/8"-16 x 3/4" Stud
19	PNYL-300100	Nylon Spacer, .750 x .406 x .200"

> Continued on next page for list of components.



LIST OF COMPONENTS:

ID#	PART NUMBER	NAME OF COMPONENT
20	PSFT-200500	Nut, Rectangular 3/8"-16, Dual Pilot
21	PTSL-800200	Rail Stop Set, Std Pair
22	PFST-200400	Nut, Rectangular 3/8"-16
23	PWFN-800100	Wonder Fence Master Hdwr Pack
24	PTSL-800600	LS Positioner (TS) Master Hdwr Pack
25	PMTL-900100	Joinery Template Set (Imperial)
26	PTSL-800100	Rail Mtg Brackets, Pair w/ Rail T-slot Hdwr
27	PMTL-900200	Master Reference Guide (Book Only)
28	PSCA-AC	Lexan Scale, Auto Centering
29	PSCA-0016R	Lexan Scale, 0"-16" (When viewed from left to right)
30	PSCA-1632R	Lexan Scale, 16"-32" (When viewed from left to right)
31	PSCA-1600S	Lexan Scale, 16"-0" (When viewed from left to right)
32	PSCA-3216S	Lexan Scale, 32"-16" (When viewed from left to right)
33	PSCA-4832S	Lexan Scale, 48"-32" (When viewed from left to right)
34	PSCA-6448S	Lexan Scale, 64"-48" (When viewed from left to right)
35	PSCA-3200SS	Stainless Steel Scale 32"-0" w/ Magnetic Tape
36	PTSL-600900	Base Clamp w/ Pad (ea)

PLEASE REFER TO THE WEBSITE FOR THE LATEST PRICING.

Refer to the part number(s) when ordering. To order, go to www.incrementaltools.com or call 1-888-804-6272.