



INCRA Wonder Fence

INCRA PARTS & COMPONENTS/
Router Fence Systems



> Continued on next page for list of components.



LIST OF COMPONENTS:

ID#	PART NUMBER	NAME OF COMPONENT
1	PWFN-700100	Infeed Fence Assembly
2	PWFN-700200	Outfeed Fence Assembly
3	PWFN-700300	High Rise Fence Cap Assembly
4	PTSL-600100	TSIIIA Bridge Fence
5	PWFN-800100	Wonder Fence Master Hdwr Pack
6	PWFN-700400	Wonder Fence Table Clamp Assembly (ea)
7	PWFN-800110	Brace Support Brackets & Mounting Hdwr A-10 for Use with Pro II Fence
8	PWFN-500300	Dust Collection Port
9	PWFN-500400	Dust Collection Elbow
10	PFST-200300	Nut, Rectangular 1/4"-20 (Narrow Body)
11	PWFN-500100	Cursor, Fence Offset
12	PNYL-100600	Nylon Screw, #10-32 x 1/4" (White)
13	PWFN-500200	Access Cover (Black)
14	PKNB-100100	Knob, #10-32 x 3/8" Stud
15	PFST-800100	Sub Fence Mounting Hardware Pack
16A	PULT-500600	Incremental Positioning Rack, 1/32" x 6"
16B	PULT-500600M	Incremental Positioning Rack, 1mm x 6"
17	PSCA-0016R	Lexan Scale, 0"-16" (When viewed from left to right)
18	PSCA-1600S	Lexan Scale, 16"-0" (When viewed from left to right)
19	PFST-900100	3/16" Ball End Hex Driver

PLEASE REFER TO THE WEBSITE FOR THE LATEST PRICING.

Refer to the part number(s) when ordering. To order, go to www.incrementaltools.com or call 1-888-804-6272.