## **MITER 5000 - SHOPSMITH EDITION**

## **IMPORTANT** - PLEASE READ BEFORE ASSEMBLY

Your new Miter 5000 Shopsmith Edition is specifically configured for, and **MUST** be used in the Right Hand Miter Slot of your Shopsmith Mark V workstation.

**DO NOT** assemble for use in the left hand miter slot as shown in the enclosed owner's manual.

During assembly, when the owner's manual makes reference to the right miter slot, instead perform the assembly instruction in the left miter slot. Conversely, when the owner's manual calls for the left miter slot, perform the assembly instruction in the right miter slot.

Refer to the photo below to maintain proper orientation during assembly.





